

## QUICK START GUIDE C27G-5S-RV



# Package Contents











°°°°

## **Overview**






## **How It Works**





# **Getting Started**



## Step 1


Mount the outdoor Omni-directional antenna to the roof of the vehicle using the provided mounting equipment. **Tips**: Near the center of the roof, At least 12 inches away from any

**Tips**: Near the center of the roof, At least 12 inches away from a other antenna, Keep the maximum distance from the window (including sunroofs).




## Step 2

Connect the cable from the Outdoor Antenna to the port labeled Outdoor on the booster.



## Step 3

Mount or place the indoor antenna to the desired location.



## Step 4

Connect the cable from the indoor antenna to the port Indoor on the booster



## Step 5

Connect the power supply cord to the end of the booster. **Tips**: If you encounter issues with installation please see the "Troubleshooting" section of the User Manual



# QUICK START GUIDE C27G-5S-BTW



# **Package Contents**













## **Overview**





## **How It Works**





# **Getting Started**




## Step 1

Clean the surface where you will place the outdoor antenna, mount the outdoor antenna by placing on top of vehicle.


Tips: Near the center of the roof, At least 12 inches away from any

**Tips**: Near the center of the roof, At least 12 inches away from a other antenna, Keep the maximum distance from the window (including sunroofs).



#### Step 2


Connect the cable from the Outdoor Antenna to the port labeled Outdoor on the booster.



## Step 3


Mount indoor antenna on the side of the seat or on the dashboard. Use the velcro adhesive strip attach to the flat side of the antenna, Then mount to desired location.

Tips: DO NOT MOUNT WHERE AIRBAGS WILL DEPLOY!



## Step 4

Connect the cable from the inside antenna to the port Indoor on the booster



## Step 5

Connect the power supply cord to the end of the booster. **Tips**: If you encounter issues with installation please see the "Troubleshooting" section of the User Manual