

QUICK START GUIDE Home SmartLink 4K



Package Contents













Signal Booster


Outdoor Antenna

Indoor Antenna Whip Antenna

Power Supply




Overview





How It Works






Getting Started




Step 1

Download the Signal Supervisor App and register an account. **Tips**: Find it in the App Store or on Google Play.



Connect the Bluetooth antenna to the "Antenna" port and tap "Add Device" on your App.


Tips: Ensure your Location Services and Bluetooth are turned on, as well as enabling their use in your phone's Privacy Settings. Stand within 20 feet of the Indoor antenna while connecting. Add your home's wireless network at this point to enable remote monitoring of your signal strength.



Step 3

Connect the Outdoor antenna.

Tips: The Outdoor antenna screws firmly into the port labeled



Step 4

Use the gauges found in the Quick Setup guide to find the best place to point your Outdoor antenna to achieve maximum gain. **Tips**: Move the antenna only about an inch at a time, then wait 45


seconds for the change to register on you App.

These readings correspond to the "Power dBm" column on your LCD

screen. -24 dBm is the worst reading, +12 dBm is the best.




DO NOT INSTALL OUTDOOR DIRECTIONAL ANTENNA IN THE CENTER OF YOUR ROOF.



Mount Outdoor antenna in the position found to have the maximum

Tips: Make sure that the drain hole in the plastic casing is facing the ground, and that the antenna itself is at least 20 feet higher in elevation than the location of your Indoor antenna.



Connect the Indoor antenna to the indoor antenna port. Mount your Indoor antenna facing 180 degrees from the direction your Outdoor antenna is pointing, and 20 feet lower in elevation.

Tips: If trying to make up the separation horizontally, be aware that at least 3 times more distance is needed than if separating vertically.



Step 7

Mount your booster up and out of reach children or pets. If you encounter issues with installation please see the "Troubleshooting" section of the User Manual.



QUICK START GUIDE Home SmartLink 10K/15K



Package Contents












Outdoor Antenna

Indoor Antenna

Power Supply




Overview





How It Works






Getting Started



Step 1


Download the Signal Supervisor App and register an account. **Tips**: Find it in the App Store or on Google Play.



Step 2

Connect the Bluetooth antenna to the "Antenna" port and tap "Add Device" on your App.


Tips: Ensure your Location Services and Bluetooth are turned on, as well as enabling their use in your phone's Privacy Settings. Stand within 20 feet of the Indoor antenna while connecting. Add your home's wireless network at this point to enable remote monitoring of your signal strength.



Step 3

Connect the Outdoor antenna.


Tips: The Outdoor antenna screws firmly into the port labeled



Use the gauges found in the Quick Setup guide to find the best place to point your Outdoor antenna to achieve maximum gain. **Tips**: Move the antenna only about an inch at a time, then wait 45


seconds for the change to register on you App. These readings correspond to the "Power dBm" column on your LCD screen. -24 dBm is the worst reading, +12 dBm is the best.





Mount Outdoor antenna in the position found to have the maximum


Tips: Make sure that the drain hole in the plastic casing is facing the ground, and that the antenna itself is at least 20 feet higher in elevation than the location of your Indoor antenna.



Step 6

Connect the Indoor antenna to the indoor antenna port. Mount your Indoor antenna facing 180 degrees from the direction your Outdoor antenna is pointing, and 20 feet lower in elevation.

Tips: If trying to make up the separation horizontally, be aware that at least 3 times more distance is needed than if separating vertically.



Step 7

Mount your booster up and out of reach children or pets. If you encounter issues with installation please see the "Troubleshooting" section of the User Manual.